


PowerShift® Installation Instructions

Controller Software Version: 4.8.138

The patented PowerShift system is designed to optimize electrical draw by adjusting voltage dynamically to match your exact RRU power requirements up to 650 feet using 4 or 6 AWG Power Cable trunks.



Section 1: PowerShift System Components / General Specifications 02

Section 2: Installation Check List 04

Section 3: General Wiring Diagram..... 05

Section 4: Configuration - Tower, Rooftop / Boost module Population Options..... 06

Section 5: RS485 Serial Connections / Input Power from DC Power Plant 07

Section 6: Redundant Boost module Population Options 08

Section 7: Power Cable Mapping 09

Section 8: Circuit Map Worksheet (Leave on-site) 10

Section 9: Rack Installation / Controller Installation 10

Section 10: Wiring of the Rack / Lug Preparation / Wiring Sequence..... 12

Section 11: Power Up and Configuration Procedure..... 16

Section 12: Closeout Package 30

Section 13: Troubleshooting Raycap Issues 31

Section 14: PowerShift Alarms and Troubleshooting..... 33

Section 15: Alarm / GP / RS485 Connectors 37

Field Engineering Services (FES)

Support services, such as our Field Engineering Services (FES) Group gives Andrew customers access to technical support where and when it is needed the most — in the field. The FES team is staffed by an expert team of technicians who, in turn, are supported by some of the brightest and most experienced product line managers.

Customer Service Center

United States and Mexico 1-888-297-6433 (technical support) or 1-888-235-5732 (main number)
International: +1-779-435-8579

For the most current, up-to-date information on all our products and product information please visit our eCatalog section at www.andrew.com.

Section 1: PowerShift System Components

The PowerShift System consists of the following components: single(PS-R-V4-M) or dual shelf(PS-R-V4-MS), one controller card(PS-CNTRL-V4), one or more modules(PS-2000-73), and Raycap OVP equipment(optional).

The PowerShift system is used in conjunction with the existing DC power plant at the installation site.

1. The shelf has capacity for 1 to 6 modules depending on configuration; bypass is integrated into module.
2. The modules are plug-and-play for easy installation and site maintenance.
3. Each module has DC input and DC output for three Remote Radio Units (RRU), for a total capacity of 9 RRU sectors per PowerShift shelf; 18 RRU sectors for a dual PowerShift shelf.
4. Each module unit is also provided with LED diagnostic indicators, explained in section 14.
5. The shelf can adjust voltage levels based on feedback(FAT) from the Raycap equipment or be used independent of a Raycap. Once the initial voltage adjustments are made the systems maintains these settings until user intervention.

Rack Part Number:


PS-R-V4-M
PS-R-V4-S
PS-R-V4-MS

Boost Module Part Number:

PS-2000-73

Pulsar Edge Controller:

PS-CNTRL-V4



General Specifications (Module)

| Electrical ¹ | Typical | Range |
|---------------------------------------|--|--|
| Input Voltage ² | -54VDC | Cut-off: -40VDC Turn-on: -44VDC ³ Maximum: -58VDC |
| Input Current ² | 15A | 0-66 A @ -40 VDC |
| Efficiency | > 97% | > 95% |
| PS Output Voltage ² | -54 VDC | -48 to -73 VDC |
| PS Output Current ² | 37.1 A | 32 A (Selectable) 37.1 A (Default) |
| Output Voltage Ripple | 400 mV rms | |
| Total Power output ⁴ | 2708 W (max boost) 2152 W (max bypass) | |
| Programmable RRU Voltage ⁵ | -54V to -58V, 0.5 Volt Increments | |
| Gauge Range | 0-6 AWG | |
| Length Range | 150-650 ft (using 6AWG power cable) ⁶ | |

¹ Per circuit; 3 circuits per module

² Input/output voltage and current range are guaranteed values, actual operating values will typically exceed these up to 10%

³ Turn-on voltage is higher than cut-off voltage in order to provide hysteresis protection

⁴ Total power = power consumed by radio + power loss in trunk cable

⁵ RRU input voltage set-point is factory programmed. Other voltage set-point are possible, contact Andrew


⁶ 650ft of 6AWG ≈ 0.54 Ohms loop resistance. Longer cable lengths are possible, contact Andrew for more information

Section 2: Installation Check List

Note:) Raycap Installation may be option depending on PowerShift Configuration does not require OVP when in Resistance Mode: Manual.

- ☐ Install OVP base and top hardware using appropriate Raycap OVP documentation (e.g. Install Instructions RCMD-6627-PF-48)
- ☐ Set OVP configuration switch as appropriate for base and top hardware (multiple base units must have unique address ID).
- ☐ Important: Ensure OVP rackmount configuration switch is set prior to rack installation (the switch may be inaccessible after rack installation)
- ☐ Install PowerShift Shelf
- ☐ Install cable (power, fiber and twisted pair) from base up to the tower/roof top (e.g., using Andrew hybrid trunk cable)
- ☐ Install cables between OVP tower/roof top hardware and remote radio units (power, fiber)
- ☐ Install power cables between DC plant circuit breakers and PowerShift Shelf input terminals
- ☐ Install power cables between PowerShift Shelf output terminals and OVP base input terminals
- ☐ Install RS485 data cable between PowerShift Shelf and OVP base hardware
- ☐ If multiple OVP base units are installed, install RS485 data cables between them (daisy chain)
- ☐ Connect trunk cables to OVP base hardware and connect to OVP tower/roof top hardware (power, twisted-pair, fiber)
- ☐ Complete all the steps in Section 11: Power Up and Configuration Procedure
- ☐ Confirm the site information and all radio circuit information has been entered in the GUI
- ☐ Confirm all the required files have been captured to your PC for inclusion in the installation closeout package
- ☐ Confirm there are no active alarms on the GUI or on the Raycap hardware
- ☐ Confirm the Circuit Map Worksheet is filled out and is left at the site
- ☐ If possible, bring the radios to full operational state (user traffic) and confirm proper operation


Section 3: General Wiring Diagram



Section 4: Configurations


12 RRU Tower Top

*Use standard Ethernet patch cable for RS485 connection




6 RRU Tower Top

*Use standard Ethernet patch cable for RS485 connection




6 or 12 RRU Roof Top

*Use standard Ethernet patch cable for RS485 connection




Section 5: RS485 Serial Connections / Input Power from DC Power Plant (Refer to Raycap for ID settings)


Tower Top



Roof Top



Section 6: Module Population Options




Note – PS-R-V4-M (9 Circuits)/PS-R-V4-MS(Option – 18 Circuits)


Built in module redundancy provides redundant functionality in the event of a boost circuit failure. Each circuit has the ability to go into bypass.

Section 7: Power Cable Mapping


6 RRU Top Dome / 6 RRU Base Rackmount (x2)



12 RRU Top Dome / 12 RRU Base Dome



Section 8: Circuit Map Worksheet (leave on-site)



| | PowerShift Circuit # | RRU # | RRU Sector | RRU Technology | Circuit Breaker # | OVP Base ID # | OVP Base Port # |
|-----------------|-------------------------|-------|------------|-------------------|----------------------|---------------|-----------------|
| Primary Shelf | 1 | | | | | | |
| | 2 | | | | | | |
| | 3 | | | | | | |
| | 4 | | | | | | |
| | 5 | | | | | | |
| | 6 | | | | | | |
| | 7 | | | | | | |
| | 8 | | | | | | |
| | 9 | | | | | | |
| Secondary Shelf | 10 | | | | | | |
| | 11 | | | | | | |
| | 12 | | | | | | |
| | 13 | | | | | | |
| | 14 | | | | | | |
| | 15 | | | | | | |
| | 16 | | | | | | |
| | 17 | | | | | | |
| | 18 | | | | | | |

Date: _____

Contractor: _____

Section 9: Rack Installation/Controller Installation

Rack Installation

- 1) Determine the installation depth required for the base unit, attach the side flanges in the appropriate location. 9 screws are required per side.
- 2) Mount the unit in a standard 19" rack near the current DC power output breaker box.
- 3) Ground the unit by installing a 6AWG ground wire at the side of the unit.
- 4) Based on the Raycap model numbers, use the applicable Raycap installation instructions to install the Raycap top and bottom OVP hardware, and the associated power and data cabling.

Controller Installation


Install the Controller into the shelf as follows

- 1) Unbox the Controller but do not remove it from the anti-static bag
- 2) Using an ESD protective wrist strap, ground yourself to the PowerShift chassis
- 3) Remove the Controller from the anti-static bag, then slide the controller all the way in until the backplane connect fully seats.

Section 10: Wiring of the Rack

Note: For ease of access, install alarm cables (if required) and RS485 data cable before installing power cables:


- 1) If required, install dry-contact alarm relay wiring from back of shelf to site alarm block.



There are two detachable terminal blocks that hold the alarm wire harness and plug into the shelf jack; this illustration shows their orientation.

To cell site alarm block

- 2) Install RS485 data cable between the Raycap base unit (VBOOST OUTPUT port) and the PowerShift shelf (R1 port); use a standard Ethernet patch cable (the cable included with Raycap RCMDC-6627-PF-48 can be used)






+ = Return (ground)
- = Supply (hot)

Communications to RayCap
OVP base (VBOOST OUTPUT)

RS485 data cable; use standard Ethernet cable or use the cable included with Raycap RCMDC=627-PF-48

- 3) As shown above, the rear of the shelf is divided into 9 or 18 individual circuits, each containing a two wire DC input and a two wire DC output. There is a positive and negative terminal strip connection for each DC input and out. Terminate the input power cables with a dual-hole lug as shown below. The output terminals should be terminated with the included Amphenol terminal plug.

Lug Preparation

| | | |
|--|---|---|
| <p>1 Prep cable end and slide heat shrink tubing onto cable</p>  | <p>2 Crimp lug to wire</p>  | <p>3 Apply heat to shrink tube</p>  |
|--|---|---|

Amphenol Preparation

PRM0400-G4-PLG 2 POSITION FEMALE QUICK CONNECT PLUG KIT. PRM SERIES™, POWER RACK MOUNT. 4.0MM MACHINED RADSOK® R8S SOCKET CONTACTS, RETAINER CLIP, WIRE RANGE 6-8AWG, 70A



SC000532-6-R4 4.0MM FEMALE SOCKET, 6-8AWG MACHINED RADSOK® R8S CONTACT




RETAINER CLIP



Burndy Y1MRTC Hand Crimping Tool



50-80639 4.0MM, EXTRACTION TOOL



Remove ferrule from packaging, look for end that has "sight window".




Strip 6AWG Telco Flex \approx 12.3mm/0.5in





Insert cable into ferrule, crimp ferrule 2 times using the 6AWG die on standard hand crimp tool



Confirm cable polarity matches connector prior to installation into Connector Body.



After both ferrules have been crimped, insert cables in Connector body and insert retaining clip



Wiring Sequence


Note: Connect PowerShift input and output power cables using the wiring sequence shown below (outside to inside, bottom to top); this is recommended based on the typical route of input and output cable into a rack (i.e., cables usually run from top of rack downward to PowerShift shelf).

- 1) Attach site DC power supply lines from the distribution panel to the input terminals on PowerShift rack
- 2) Attach power output cables from the PowerShift rack to the OVP base panel/box.
- 3) Repeat for each circuit. Recommend completely wiring all input and output cable pairs into the shelf during installation, even if 9 or 18 modules are not being installed; this will ease future installation of additional radios.


Wiring Sequence A-F (outside to inside, bottom to top)

Sequence cable installation from Right to Left and stagger as shown in picture below.


PS-R-V4-M MAIN SHELF



PS-R-V4-S MAIN SHELF



PS-R-V4-MS DUAL SHELF



Section 11: Power Up and Configuration Procedure

Note: Module Hot Swap

If a module is removed during operation the power to the radio will be lost.

The controller card can be hot swapped while the system is operational, power to the radios will not be interrupted. However note the following:

- The modules will re-adjust their boosted voltage output based on the load current demanded by the radio and the newly calculated ALR.
- If there are other large changes to circuit conditions, such as a significant change in cable resistance, operational adjustments will be made when the controller is installed.

Apply Input Power

- 1) Turn on DC plant circuit breaker for PowerShift Module 1, confirm activation of the Controller, LCD Display

Note: The Controller, Display obtain power from the Shelf input terminals, at least one circuit must have input power applied.


- 2) The Controller LEDs should cycle off and on, the LCD display backlight should illuminate
- 3) After 10-30 seconds:
 - a) The Controller card SYS LED should illuminate solid green or red
 - b) The Display should show the text "U" in the center/left of the screen (the backlight may be either green, yellow or red)



- 4) Use a Windows PC and web browser (Chrome is preferred) to connect to the LAN port on the back(PS-R-V4-M) or front(PS-R-V4-MS) of the PowerShift Shelf
 - a) Connect a standard Ethernet patch cable between the PC and the Shelf LAN port; the PC Ethernet port LED should illuminate
 - b) The PC must be configured for DHCP operation on its Ethernet port
- 5) Open web browser on the PC and enter URL: 192.168.2.1, the GUI login page appears:



Note: When the Controller is powered up it may take 1-2 minutes before the web browser can connect, and then it may take 30 seconds or longer for the login page to appear

Troubleshooting: If the login page does not appear, open a command prompt (cmd) in Windows and use the following ping command to confirm a good connection to the controller: ping http://192.168.2.1



The login screen features the PowerShift logo at the top left. Below it, there is a large light blue rectangular area. In the bottom right corner of this area, the text "Enter Password" is displayed next to a padlock icon. Below this text is a password input field labeled "Password:" and a "Submit" button.

- 6) Enter the password: super-user (lower case, no spaces)
 - a) The default login does not require a user name, only a password
 - b) Click Submit, the GUI Home page appears:
 - c) Confirm the controller software version is 4.8.138 or higher
 - d) Click on the Installation tab, adjust the time and date, enter the site ID and description (e.g., site name or street address); click the Submit button

The GUI Installation page shows the same top navigation bar. The main content area displays system inventory information, including Comcode, CLEI, Series, Board Code, Serial Number, Boot Block, Application, Web Pages, Defaults, and Modbus. Below this, it shows the "Number of PowerShift Modules" and a section titled "Set Basic System Information". This section includes fields for "Enter the Site ID:", "Enter the Site Description:", "Shelf J-Code or Product Code:", "Set the date for this system:", and "Set the time for this system:". There is a "Submit" button and a "Change Language" link at the bottom.


- 7) If it is required to disable a Controller communication port for security purposes (such as HTTP), then use the following steps:
 - a) In the GUI, click on the Settings tab, then click on the Security hotlink
 - b) Under Enabled Network Ports, uncheck ports to disable them

Warning: If you uncheck "Enable HTTP" and submit the change, the port will be disabled and you will lose the GUI connection; you will then need to use HTTPS to connect (//https:192.168.2.1)

- c) Click the Submit button

Inserting Modules

- 1 Slide module partially into rack slot
- 2 press metal release tab to open front cover, slide module into rack until it stops
- 3 Close the front cover on the module to make connection and lock into place. Repeat with any remaining modules. The modules operate individually so slots may be left open for future expansion.



- 8) Insert a module into Shelf slot 01, the following Shelf LED behavior should occur:
 - a) Module LED (Circuit 1/Circuit 2/Circuit 3) blinks green and Module LED (Module) constant green.
 - b) After 10-30 seconds Module LED (Circuit 1/Circuit 2/Circuit 3) blinks green and Module LED (Module) constant green; this is the normal state and indicates output power is now active to the OVP base and the Module status is in Bypass.

Note: If OVP Traffic icon is Gray that means it has never turned on. Enable Auto Mapping or Manually assign circuit.

-
- Switch position 2-6

-

The screenshot displays the APC UPS web interface. At the top, there are navigation tabs: Home, Reports, Maintenance, Settings, Installation, Software, and Logout. Below the tabs, a status bar shows: USER: ADMINISTRATOR, DATE: 09/07/2024, TIME: 09:05:13, IP: 10.01.180.20, APP: 4.0.130, and WEB: 4.0.130. Below the status bar are three buttons: '2 Record-Only Items', 'Clear Missing Devices...', and 'Clear PowerShift Faults'. The main content area is titled 'Main Shelf' and includes a checkbox for 'Enable Auto Mapping' and a green 'OVP Traffic' button. On the left, under 'PS Module 01', there are three circuit status cards (01, 02, 03) showing voltage and current readings. Circuit 01 is in 'Auto' mode, Circuit 02 is in 'Auto' mode, and Circuit 03 is in 'Manual' mode. A 'Module Input Current: 70.19 A' is displayed at the bottom left. The right side of the main shelf shows two large empty boxes labeled '02' and '03'. Below the main shelf is a section for the 'Secondary Shelf'.


| Circuit | Output | Upper Voltage (V) | Lower Voltage (V) | Current (A) | Mode |
|---------|--------|-------------------|-------------------|-------------|--------|
| 01 | BOOST | 53.30 | 64.38 | 29.63 | Auto |
| 02 | BOOST | 53.40 | 61.05 | 20.00 | Auto |
| 03 | BYPASS | 51.79 | 53.30 | 10.13 | Manual |

Module Input Current: 70.19 A

Perform OVP Circuit Assignment

12) Auto Mapping

- The PowerShift Shelf has the ability to automatically map circuits based on wiring and upper voltage feedback.
- This required the circuit to be fully wired and the modules installed. Once installed the user must "Enable Auto Mapping". This will force the circuit to be assigned based on OVP wiring.
- Once enabled "Assign OVP" will change to "Mapping in Progress" to "OVP XXX" depending on the mapped location.




13) Manual Mapping


The following steps describe an OVP circuit assignment using the PowerShift GUI; explanation:

- The PowerShift Shelf is receiving the upper voltage measurement from the OVP base
- This next step assigns that measurement to the applicable Shelf circuit (Circuit 01 in this case)
- Once the assignment is made, PowerShift will adjust its output voltage based on the upper measurement voltage reported by the OVP


14) In the GUI Home page, the OVP circuit assignments are made by clicking anywhere inside the circuit box



15) The circuit information pop-up box is displayed; the annotated labels describe the circuit information provided




- 16) Click on the OVP Assignment box to display the list of available OVP upper voltage measurements; note the following using the example below:
- “Base: 0” is the address of the OVP base unit that receives the upper voltage measurement and sends it to the PowerShift shelf
 - “Port: 1” identifies the port number of the OVP top unit that sends the upper voltage measurement to the OVP base unit



- 17) Select the applicable OVP assignment from the list
 - a) Scroll down the list as needed to find and click on the desired OVP base ID and port number
 - b) Click the "X" in the upper right corner to close the OVP assignment box and return to the Home page
- 18) Check LCD Display to confirm the Upper Voltage measurement is displayed; following is an example after assignments are made for Circuit 01 thru 03 for Module 1.



Note: The LCD main screen displays the upper voltage measurements for each module followed by each circuit after the upper voltage has been assigned to a Shelf circuit. The voltages are displayed in a 4x3 grid; example:




Perform Measurement Sanity Check

- 19) Using the GUI, perform a sanity check on the detailed circuit measurements using the following guidelines:
 - a) Input Voltage: Roughly equal to DC plant rectifier float voltage; typically about 54.0V to 54.5V
 - b) Lower Voltage: Around 56V or higher; the longer the trunk cable and greater the radio power demand, the greater the voltage (e.g. ~65V for 1500W RRU load and 500ft of 6-AWG)
 - c) Upper Voltage: 53.5 +/- 3V
 - d) Output Current: Greater than 0; exact value will vary significantly depending on radio model and user traffic demand
 - e) Auto Line Resistance: Varies depending on cable length and gauge; very general guideline is between 0.10 and 0.20 (may be higher for very long cable lengths and/or lighter cable gauge)

Enter Radio Information

- 20) In the GUI circuit pop-up box, enter the radio information (sector, technology, band) and enter the ID for the DC plant circuit breaker that provides input power to the shelf. A color code for the trunk cable can also be entered.




Power Up Remaining Circuits

- 21) Repeat the previous steps for each circuit, one circuit at a time:
- Turn on the circuit breaker
 - Insert additional module as needed
 - Confirm the OVP base displays lower and upper voltage measurements
 - Perform the OVPRM circuit assignment
 - Confirm the LCD Display shows the circuit measurements
 - Perform sanity check on circuit measurements
 - Insert additional Module as needed
 - Enter the radio information for the circuit into the GUI

Disabling a Circuit


- 22) In some cases there will be one circuit in a PowerShift module that is powered, but the second and/or third circuit is unpowered (no radio is installed on the circuit)
- 23) In this case it is necessary to disable the unpowered circuit using the GUI
- 24) In the GUI, click inside the module box of the circuit that is to be disabled (Slot 01, Circuit 01, in this example), then click on the button "Disable this Circuit"; confirm the prompt to disable the circuit




- 25) The GUI will show the circuit as disabled; the module LEDs for the circuit will turn off.

Note: You will be giving a prompt that "This will reset circuit settings to default! Circuit shuts down if auto-mapping is enabled."


Warning: This action will disconnect power any device connected to this circuit.



26) In order to clear the "MISSING" flag, click on the button "Clear Missing Devices"



27) Summary of Main GUI



Configure Alarm Notification

28) In the GUI, click on the Settings tab, then click on the Alarm Notification link

HomeReportsMaintenance**Settings**InstallationSoftwareLogout

USER: SUPER-USER DATE: 08/12/2024 TIME: 08:31:28 IP: 10.61.180.20 APP: 4.8.101 WEB: 4.8.101

Please select which settings you would like to adjust:

| System | Communication | Programming |
|--------------------------------|------------------------------------|-------------------------------------|
| Date/Time/Temp | Passwords | User Defined Events |
| Alarm Test | Security | |
| PowerShift | Network | |
| Load Shedding | Modbus | |
| Part Numbers | SNMP | |
| | Email | |
| | Alarm Notification | |
| | UDE Notification | |

29) In the Alarm Notification page, ensure the severity ("Sev.") and Relay columns are configured for each alarm section as shown in the screen captures below:

30) System Alarms

Notify Settings

Critical Equals Major ☒

Enable Enhanced Relays ☐

| System Alarms | ID | Sev. | Relay | LED | EMAIL | SNMP | PHONE | Delay |
|---|-------|------|-------|-----|---------|---------|---------------|-------|
| | | | | | 1 2 3 4 | 1 2 3 4 | 1 2 3 4 O R N | |
| High Ambient Temperature | AMTH1 | MAJ | R2 | | | | | 0s |
| Low Ambient Temperature | AMTL1 | MAJ | R2 | | | | | 0s |
| Config Reboot Required | CRT1 | CRIT | R1 | | | | | 0s |
| Auxiliary Major | AMJ1 | CRIT | R1 | | | | | 0s |
| Alarm Test Active | ATA1 | RO | | | | | | 0s |
| Alarm Test Aborted | ATB1 | RO | | | | | | 0s |
| Real Time Clock Battery Low | BBL1 | WRN | | | | | | 0s |
| Configuration Changed | CCH1 | RO | | | | | | 0s |
| Clock Changed | CLC1 | RO | | | | | | 0s |
| ID Conflict | DID1 | CRIT | | | | | | 0s |
| Excessive Login Attempts | EXL1 | WRN | | | | | | 0s |
| History Cleared | HCL1 | RO | | | | | | 0s |
| Password At Default | PFD1 | RO | | | | | | 0s |
| Processor Halt | PHT1 | RO | | | | | | 0s |
| Self Test Failed | STF1 | MAJ | R2 | | | | | 0s |
| ID Not Configured | ZID1 | CRIT | R1 | | | | | 0s |

Click buttons to change

31) Communication Alarms

| Communication Alarms | ID | Sev. | Relay | LED | EMAIL | SNMP | PHONE | Delay |
|--|------|------|-------|-----|---------|---------|---------------|-------|
| | | | | | 1 2 3 4 | 1 2 3 4 | 1 2 3 4 O R N | |
| Minor Communication Fail Alarm | CMA1 | MAJ | R2 | | | | | 0s |
| Queue Overflow | COF1 | WRN | | | | | | 0s |
| No Call-Out Response | COR1 | WRN | | | | | | 0s |
| Major Communication Fail Alarm | MCM1 | CRIT | R1 | | | | | 0s |
| Unconfigured Alarm Destination | NNC1 | WRN | | | | | | 0s |
| No Dial-Out Response | POR1 | WRN | | | | | | 0s |
| External Password Reset | EPR1 | WRN | | | | | | 0s |

32) PowerShift Alarms

Note: Changes can be made quickly by clicking on Sev button and Relay button; for example:

Click on the "Relay" column header and select "R1"; this will change all alarms to R1

For alarms with MAJ severity, change the relay to "R2"

| Voltage Boost Alarms | | ID | Sev. | Relay | LED | EMAIL | | | | SNMP | | | | PHONE | | | | | | | Delay |
|--|--|-------|------|-------|-----|-------|---|---|---|------|---|---|---|-------|---|---|---|---|---|---|-------|
| | | | | | | 1 | 2 | 3 | 4 | 1 | 2 | 3 | 4 | 1 | 2 | 3 | 4 | O | R | N | |
| Incompatible PowerShift | | ICLD1 | CRIT | R1 | | | | | | | | | | | | | | | | | 0s |
| OVP System H2O | | TH2O1 | CRIT | R1 | | | | | | | | | | | | | | | | | 0s |
| OVP System Intrusion | | TINT1 | CRIT | R1 | | | | | | | | | | | | | | | | | 0s |
| OVP System Power | | LTP1 | CRIT | R1 | | | | | | | | | | | | | | | | | 0s |
| OVP Upper Voltage Out of Range | | LUV1 | CRIT | R1 | | | | | | | | | | | | | | | | | 0s |
| OVP Upper to Lower Comm | | TBC1 | CRIT | R1 | | | | | | | | | | | | | | | | | 0s |
| PowerShift AutoResistance Fail | | ARF1 | MAJ | R2 | | | | | | | | | | | | | | | | | 0s |
| PowerShift Boost Over Temp | | RCO1 | CRIT | R1 | | | | | | | | | | | | | | | | | 0s |
| PowerShift Disabled Cct Power | | LDCP1 | RO | | | | | | | | | | | | | | | | | | 0s |
| PowerShift Fuse Fail | | RFF1 | CRIT | R1 | | | | | | | | | | | | | | | | | 0s |
| PowerShift ID Conflict | | RRID1 | MAJ | R2 | | | | | | | | | | | | | | | | | 0s |
| PowerShift Input Fail | | RIP1 | CRIT | R1 | | | | | | | | | | | | | | | | | 0s |
| PowerShift Interlock Open | | RIO1 | CRIT | R1 | | | | | | | | | | | | | | | | | 0s |
| PowerShift Module Mismatch | | LMIS1 | RO | | | | | | | | | | | | | | | | | | 0s |
| PowerShift Module Over Temp | | RMT1 | CRIT | R1 | | | | | | | | | | | | | | | | | 0s |
| PowerShift Multiple Fan Fail | | RMF1 | CRIT | R1 | | | | | | | | | | | | | | | | | 0s |
| PowerShift Output V Out of Rng | | ROV1 | MAJ | R2 | | | | | | | | | | | | | | | | | 0s |
| PowerShift Overload | | ROL1 | CRIT | R1 | | | | | | | | | | | | | | | | | 0s |
| PowerShift Primary Fault | | LPRI1 | CRIT | R1 | | | | | | | | | | | | | | | | | 0s |
| PowerShift Redundancy Loss | | LRLS1 | MAJ | R2 | | | | | | | | | | | | | | | | | 0s |
| PowerShift Resistance | | LRES1 | CRIT | R1 | | | | | | | | | | | | | | | | | 0s |
| PowerShift Single Fan Fail | | RSF1 | CRIT | R1 | | | | | | | | | | | | | | | | | 0s |
| PowerShift Translator Timeout | | TPT1 | CRIT | R1 | | | | | | | | | | | | | | | | | 0s |
| PowerShift Upper Voltage Low | | PUVL1 | MAJ | R2 | | | | | | | | | | | | | | | | | 0s |
| PowerShift Voltage Not Linked | | LVNL1 | CRIT | R1 | | | | | | | | | | | | | | | | | 0s |
| Manual Resistance Not Set | | MRNS1 | MAJ | R2 | | | | | | | | | | | | | | | | | 0s |

Click "Relay" button to assign all to "R1", then click the alarms with "MAJ" and change to "R2"

Section 12: Closeout Package

Once the installation is complete and all alarms are cleared, use the following procedure to capture information for inclusion in the site installation closeout package

Capture the Circuit Map Worksheet

- Fill out the Circuit Map Worksheet (located on page 9)
- Obtain a photo of the completed worksheet and save it as a jpg file to your Windows PC

Capture Alarm History Report

- In the GUI, click the Maintenance tab and clear the alarm history using the “clear alarm” button (the pull-down list underneath it should be set to “Alarm”)
- Click the Reports tab, then click the Alarm History hotlink
- Click the Print Event History button to generate a pdf file, save it to your Windows PC

Capture Inventory Report

- In the GUI, click the Reports tab, then click the Inventory Report tab; it may take a minute for the report to generate
- To generate a pdf file, click the small printer icon in the upper right corner of the Inventory banner
- Important: Set the Layout to Landscape, save the pdf file to your Windows PC

Capture Home Page

- In the GUI, click on the Home tab
- Obtain a screen capture of the Home page, save it as a jpg file to your PC

Capture Circuit Pop-up Boxes

- In the GUI Home page, click on each boost module circuit to open the pop-up box
- Note that multiple pop-up boxes can be opened at the same time, they can be moved around on the page and resized as needed; this allows you to arrange at least four circuits on the page before obtaining a screen shot
- Obtain multiple screen shots as needed to capture all the boost module circuits, save them as jpg files to your Windows PC

Section 13: Troubleshooting Raycap Issues

Raycap Displays Shows 0V (example using L1/U1)

L1 voltage is 0: If Circuit 01 on the PowerShift shelf has input power and it has output voltage, then there is a possible problem with the output cabling from the PowerShift shelf to the OVP base. For example, a cross-wiring mistake where the shelf Circuit 01 output cable is connected to the wrong terminals on the OVP base


U1 voltage is 0: If the L1 voltage is not 0V, then there is a possible problem with the trunk power cables or with the twisted-pair cables between the OVP base and OVP top. Press the Wake/Adv button on the OVP base to cycle through the other measurements (L2/U2, L3/U3, etc.) to confirm they all report 0 voltage; if any non-zero voltages are observed this probably indicates a cross-wiring problem

Raycap Base OVP Alarm Condition:

The Raycap OVP base has three LEDs that illuminate red in case of an error:

- Intrusion: The top OVP cover is removed (or the intrusion micro-switch could be bad)
- H2O: The top OVP has water or high moisture content
- Power: There are several possible alarm conditions, see below

The Raycap Voltage display and the Power Alarm LED may present as one of the three scenarios shown below



Low Voltage
(less than 35V)

Reverse Polarity

Short Circuit


General Description:

- “Lo” = Low voltage condition
(voltage at base or at top is <35V)
- “PL” = Polarity reversal condition
(the supply and return cables are swapped)
- “SH” = Short-circuit condition
(the supply and return cables are shorted together)


Following is a more detailed description of possible Power Alarm LED and Voltage display error conditions (using L1/U1 as an example):

| L1 (lower) | U1 (upper) | Power Alarm LED | Possible Cause |
|--------------------|---------------|--------------------|---|
| Lo | Lo | Off | This is the expected, nominal condition for a circuit that is fully cabled but is not powered (i.e. the circuit breaker is open, or PowerShift boost and bypass modules are both not installed, or PowerShift circuit output is disabled). Note that in this configuration there will be a 30-33V is present on the circuit; it is a "sensing voltage" the Raycap OVP uses to confirm the status of an unpowered circuit. |
| Lo | Lo | On | Should only occur if the top OVP is a model 3315 (non-retrofit) and the sensing voltage is being dragged down to <24V (which is likely caused by an unexpected load current on the circuit). |
| Lo | 00 | - | Trunk cable pair is not connected between base and top OVPs. Or if top OVP is a model 3315 (non-retrofit) then voltmeter twisted-pair may be disconnected between base and top OVPs (see Note1 below). |
| Lo (or) >54V | PL | On | The trunk cable supply/return cables are swapped at the terminal block on the base OVP or on the top OVP. Or if the top OVP is a model 3315 (non-retrofit) then voltmeter twisted-pair may be swapped or disconnected (see Note1 below) |
| SH | SH | On | There is a short circuit between supply/return cables; could be located at base OVP terminals, top OVP terminals or somewhere within the trunk cable. |
| SH | 00 | On | Should only occur if top OVP is a model 3315; the circuit is shorted and the voltmeter twisted-pair may be disconnected between base and top OVP (see Note1 below). |
| >54V | Lo | Off | Should only occur if top OVP is a model 3315; the trunk supply cable may be disconnected (and the return cable is connected) |
| >54V | 00 | Off | Trunk cable pair is not connected to top OVP. Or if top OVP is a model 3315 (non-retrofit) then the trunk return cable may be disconnected (and the supply cable is connected), or the voltmeter twisted-pair may be shorted (see Note1 below). |

Note: Following is the location of the terminal blocks that connect the volt meter twisted-pair



3315 OVP dome



2260 Rackmount

Section 14: PowerShift Alarms and Troubleshooting

Boost and Bypass Module LEDs

There are four status indicators on each Boost module and Bypass Module: P-In, P-Out, S-In, S-Out:

- 1) P-In and P-Out represent the status of the input and output circuits (respectively) of the first circuit in a boost module or bypass module.
- 2) S-In and S-Out represent the status of the input and output circuits (respectively) of the second circuit in a boost module or bypass module.

The following table provides a summary of LED status and the corresponding operational status of the hardware.

Power and Bypass Module Operational State

| | Condition | Circuit 1 | Circuit 2 | Circuit 3 | Module |
|----|--|-----------|-----------|-----------|---------|
| | | G/Y/R | G/Y/R | G/Y/R | G/Y/R |
| 1 | All Circuits in Boost state and OK | G | G | G | G |
| 2 | Circuit 1 Boost state | G | - | - | G |
| 3 | Circuit 1 Bypass state | G Blink | - | - | G |
| 4 | Circuit 1 External Fault (e.g. Vin OV, OCP) | Y | - | - | Y Blink |
| 5 | Circuit 1 Stand-by (circuit output turned off, but circuit active on GUI) | Y Blink | - | - | G |
| 6 | Circuit 1 Internal Fault (e.g. Fuse, Vout OVP) | R | - | - | R |
| 7 | Circuit 1 Input not present, circuit 1 disabled (no circuit or any parameter tracked on GUI) | Off | - | - | G |
| 8 | Circuit 1 Thermal fault recovered, but not reset | Y Blink | - | - | Y |
| 9 | Circuit 2 Boost state | - | G | - | G |
| 10 | Circuit 2 Bypass state | - | G Blink | - | G |
| 11 | Circuit 2 External Fault (e.g. Vin OV, OCP) | - | Y | - | Y Blink |
| 12 | Circuit 2 Stand-by (circuit output turned off, but circuit active on GUI) | - | Y Blink | - | G |
| 13 | Circuit 2 Internal Fault (e.g. Fuse, Vout OVP) | - | R | - | R |
| 14 | Circuit 2 Input not present, circuit 2 disabled (no circuit or any parameter tracked on GUI) | - | Off | - | G |
| 15 | Circuit 2 Thermal fault recovered, but not reset | - | Y Blink | - | Y |
| 16 | Circuit 3 Boost state | - | - | G | G |
| 17 | Circuit 3 Bypass state | - | - | G Blink | G |
| 18 | Circuit 3 External Fault (e.g. Vin OV, OCP) | - | - | Y | Y Blink |
| 19 | Circuit 3 Stand-by (circuit output turned off, but circuit active on GUI) | - | - | Y Blink | G |
| 20 | Circuit 3 Internal Fault (e.g. Fuse, Vout OVP) | - | - | R | R |
| 21 | Circuit 3 Input not present, circuit 3 disabled (no circuit or any parameter tracked on GUI) | - | - | Off | G |
| 22 | Circuit 3 Thermal fault recovered, but not reset | - | - | Y Blink | Y |
| 23 | Defective single Fan (not immediate service needed) | - | - | - | Y |
| 24 | Any Service Creating an Internal Fault | - | - | - | R |
| 25 | Communication Fail | - | - | - | R Fast |

¹ Normal operating state for the Boost module and Bypass module

² If only one module circuit has input power, the other circuit will show yellow solid on the Input LED for (boost and bypass modules); the alarm condition can be cleared by disabling the unpowered circuit in the GUI

³ If a boost module circuit has failed or if the boost module has been removed from the shelf, the bypass module will show green solid on the input LED and yellow solid on the output LED

The following information provides additional details and troubleshooting guidelines on the LED status

No Light

- 1) Input not present or circuit is disabled.

Green

- 1) A solid green status light indicates the circuit is functioning properly
 - a. Circuit is in Boost State and OK

Yellow

- 1) A solid yellow status light on 1, 2, or 3 - indicates the circuit has an external fault; this occurs when V_{in} overvoltage or Over-Current-Protection on that circuit.
 - b. Input voltage out of range, either $< 38VDC$ or $> 58 VDC$; check output voltage at DC plant rectifier.
 - c. Short-circuit on the output cables, short-circuit or over-load condition at the RRU; the affected circuit will likely show solid green on the input and yellow wink on the output
- 2) A winking yellow status light on 1, 2, or 3 - indicates a Standby or Thermal Fault. The indicated circuit is not powered; the external fault maybe caused by the following:
 - a. Yellow may indicate a minor alarm that does not require immediate attention, but can be corrected in a service window. One example is the failure of one of the two fans in the module. The module will run, but should be replaced at earliest convenience.
- 3) After correcting the fault, the circuit can be returned to normal operation by toggling the DC plant breaker for that circuit

Red

- 1) A red winking status light on 1, 2, 3, or X - indicates an Internal Fault
 - a) During initial application of input power to the circuit (LED should change to solid green after 10-30seconds)
 - b) Whenever the controller is inserted into its slot or if it reboots (LED should change to solid green after 10-30 seconds)
 - c) The circuit input voltage is above the maximum threshold ($>58VDC$)

GUI Alarms

The following table lists all of the PowerShift alarms generated in the GUI; active alarms are viewable in the GUI Home page, and the Reports tab provides an Alarm History report.

| GUI Alarm Description | Alarm Type | Severity | Relay | Description [Troubleshooting] |
|---------------------------------|------------|-----------|-------|---|
| High Ambient Temperature | System | Major | 2 | Shelter/cabinet air temperature is above acceptable range |
| Low Ambient Temperature | System | Major | 2 | Shelter/cabinet air temperature is below acceptable range |
| Config Reboot Required | System | Critical | 1 | "Controller must be rebooted due to a configuration change (Reboot using GUI or reseal the controller to power cycle it)" |
| Auxiliary Major | System | Critical | 1 | N/A for PowerShift |
| Alarm Test Active | System | Read Only | | Indicates user has initiated test of the alarm relays. True while test is active |
| Alarm Test Aborted | System | Read Only | | User alarm test was aborted due to an actual alarm condition |
| Real Time Clock Battery Low | System | Warning | | The lithium battery in the controller RTC should be replaced |
| Configuration Changed | System | Read Only | | User has changed the system configuration |
| Clock Changed | System | Read Only | | User has changed the system time/date |
| ID Conflict | System | Critical | 1 | Indicates a problem with one or more boost or bypass modules |
| Excessive Login Attempts | System | Warning | | User has tried to login with an invalid password - three failed attempts |
| History Cleared | System | Read Only | | User has cleared history logs for alarm history or other history logs |
| Password At Default | System | Read Only | | The login passwords are at factory default |
| Processor Halt | System | Read Only | | The controller processor has stopped; controller was unseated in the shelf or power is otherwise removed from the controller. Entry is written during boot up based on RTC flag |
| Self Test Failed | System | Major | 2 | N/A for PowerShift |
| ID Not Configured | System | Critical | 1 | Boost or bypass module has an ID that is outside valid range |
| Minor Communication Fail Alarm | Comms | Major | 2 | Controller has lost communication with one boost or one bypass module |
| Queue Overflow | Comms | Warning | | N/A for PowerShift; applies only when a modem is used |
| No Call-Out Response | Comms | Warning | | N/A for PowerShift; applies only when a modem is used |
| Major Communication Fail Alarm | Comms | Critical | 1 | Controller has lost communication with multiple boost/bypass modules |
| Unconfigured Alarm Destination | Comms | Warning | | Alarm is configured to alert via dial-out or SNMP, but no destination has been defined |
| No Dial-Out Response | Comms | Warning | | N/A for PowerShift; applies only when a modem is used |
| External Password Reset | Comms | Warning | | N/A for PowerShift |
| Incompatible PowerShift | PowerShift | Critical | 1 | The controller has detected PowerShift V1 boost modules installed in the shelf; only V2 modules may be used with PowerShift V2 shelf |
| OVP System H2O | PowerShift | Critical | 1 | OVP alarm due to water ingress sensor activating on OVP dome unit |
| OVP System Intrusion | PowerShift | Critical | 1 | OVP alarm due to dome unit cover having been loosened or removed |
| OVP System Power | PowerShift | Critical | 1 | OVP alarm due to a power issue on one or more circuits |
| OVP Upper Voltage Out of Range | PowerShift | Critical | 1 | The reported radio input voltage is outside expected range (37V to 60V) |
| OVP Upper to Lower Comm | PowerShift | Critical | 1 | The OVP is reporting loss of communication between base unit and tower top unit(s) |
| PowerShift Auto Resistance Fail | PowerShift | Major | 2 | PowerShift was unable to complete a line resistance calculation for a circuit |
| PowerShift Boost Over Temp | PowerShift | Critical | 1 | "The PowerShift boost/bypass module has exceeded its operating temperature [Check for failed fan alarm on module; check the shelter or cabinet cooling system]" |
| PowerShift Disabled Cct Power | PowerShift | Read Only | | The circuit(s) of the module have been disabled. |
| PowerShift Fuse Fail | PowerShift | Critical | 1 | The PowerShift boost converter module has a failed internal fuse; replace the module |
| PowerShift ID Conflict | PowerShift | Major | 2 | Possible issue with the PowerShift shelf unit |
| PowerShift Input Fail | PowerShift | Critical | 1 | PowerShift has lost input power to a circuit; the circuit previously had input power applied and a boost/bypass module was installed for the circuit |

Cont.

| GUI Alarm Description | Alarm Type | Severity | Relay # | Description [Troubleshooting] |
|--------------------------------|------------|-----------|---------|---|
| PowerShift Interlock Open | PowerShift | Critical | 1 | "Boost or bypass module is improperly seated in the shelf, or the module backplane is damaged, or the shelf backplane is damaged [Reseat modules; inspect backplane of modules for any obvious dam-" |
| PowerShift Module Mismatch | PowerShift | Read Only | | An incorrect module type has been installed. Inspect the module and confirm correct type installed. |
| PowerShift Module Over Temp | PowerShift | Critical | 1 | "The air inlet temperature to the module is above threshold temperature setpoint [Check shelter or cabinet cooling system]" |
| PowerShift Multiple Fan Fail | PowerShift | Critical | 1 | Both fans in a PowerShift boost or bypass module have failed; replace the module |
| PowerShift Output V Out of Rng | PowerShift | Major | 2 | "PowerShift boost module output voltage has exceeded the maximum output voltage of 73V [Should not occur unless module is faulted; replace the module]" |
| PowerShift Overload | PowerShift | Critical | 1 | "The output current on a PowerShift circuit has exceeded the specified maximum value of 30A, the module has turned off its output; if circuit over-current condition clears within 20 minutes, then module will re-enable output [Check for short-circuit on cable or radio; check for radio drawing excessive current]" |
| PowerShift Primary Fault | PowerShift | Critical | 1 | "A boost and bypass module pair are simultaneously trying to supply load current to a circuit [Unseat bypass module then reseat, if problem persists then swap in a different boost or bypass module to determine which module is faulted]" |
| PowerShift Redundancy Loss | PowerShift | Major | 2 | One or more PowerShift circuits has lost redundant backup power on a circuit; this can be due failure of a boost or bypass module, removal of a boost or bypass module for maintenance purposes, etc. |
| PowerShift Resistance | PowerShift | Critical | 1 | The line resistance calculated by PowerShift has a value exceeding 1 Ohms; this indicates a problem condition with the line or misapplication of the product |
| PowerShift Single Fan Fail | PowerShift | Critical | 1 | One fan in a PowerShift boost or bypass module has failed; replace the module |
| PowerShift Translator Timeout | PowerShift | Critical | 1 | "Communication failure between PowerShift shelf and OVP base unit [Check RS485 cable connection from OVP Boost Output port to PowerShift shelf R1 port]" |
| PowerShift Upper Voltage Low | PowerShift | Major | 2 | The reported radio input voltage is lower than the minimum expected voltage of 37V |
| PowerShift Voltage Not Linked | PowerShift | Critical | 1 | A PowerShift circuit has input power applied and its output power is enabled, but the GUI has not been configured to link an OVP voltage measurement to the circuit |
| Manual Resistance Not Set | PowerShift | Major | 2 | The trunk cable resistance of the circuit has not be established. |

PowerShift Output Overload Protection

The boost module is designed to shut off its output circuit in the event the load demand exceeds the circuit maximum output capacity of 2708W total power (radio demand + power loss in the trunk cable)

Under normal circumstance an output overload should not occur; the proper design and installation of the PowerShift system ensures the maximum radio load demand and the trunk cable length do not exceed the circuit capacity.

However, off-nominal events such as a short in the trunk cable or a malfunctioning radio could cause the load demand to exceed the module output capacity. In this event the module functions as follows:

When circuit capacity is exceeded the module will shut off its output

The module then checks the condition of the circuit periodically (about every 5 seconds) to determine if the overload condition remains or if it has cleared


If the overload condition clears, the module will re-enable output on the circuit

If the overload condition has not cleared, the module will continue to keep the circuit output shut off and will continue to check the circuit condition about every 5 seconds

After 20 minutes, if the circuit overload condition has not cleared, the module will latch the circuit output off and will discontinue checking the circuit condition

Once the circuit is latched off, the user must intervene to re-enable it; the overload condition must be cleared and the circuit can then be re-enabled by cycling the input power breaker or by using the GUI to disable/enable the circuit

Section 15: Alarm/GP/RS485 Connectors



Technical Support

+1 888 297 6433, Option 3 (Toll Free US and Canada)

+1 828 323 4220, Option 3 (local) <https://www.Andrew.com/support> (open a ticket)

Notice: Andrew disclaims any liability or responsibility for the results of improper or unsafe installation, inspection, maintenance, or removal practices.
Aviso: Andrew no acepta ninguna obligación ni responsabilidad como resultado de prácticas incorrectas o peligrosas de instalación, inspección, mantenimiento o retiro. Avis : Andrew décline toute responsabilité pour les conséquences de procédures d'installation, d'inspection, d'entretien ou de retrait incorrectes ou dangereuses.

Hinweis: Andrew lehnt jede Haftung oder Verantwortung für Schäden ab, die aufgrund unsachgemäßer Installation, Überprüfung, Wartung oder Demontage auftreten. Atenção: A Andrew abdica do direito de toda responsabilidade pelos resultados de práticas inadequadas e sem segurança de instalação, inspeção, manutenção ou remoção. Avvertenza: Andrew declina eventuali responsabilità derivanti dall'esecuzione di procedure di installazione, ispezione, manutenzione e smontaggio improprie o poco sicure.

注意：Andrew 对于因不当或不安全的安装、检查、维护或拆除操作而导致的后果，我们不承担任何责任